




DIAMOND MULTI PIN EXTRACTOR

The Diamond Multi Pin Extractor is designed for disassembly of roller chains up to size 16B or ANSI 80, single strand.

TO USE:

Begin by grinding the desired pin heads flush with the linkplate. Then, select the correct chain model on the carousel and insert the chain at the point you wish to remove the pin(s) from. Ensure that the pressure pins are resting on the center of each chain pin. Next, pull the lever down and use continuous pressure to force the pins from the chain. Once the pins have been removed, replace the lever to the upright position and disassemble the chain.



For more information about this product, scan the QR code to contact your Diamond Chain Support Specialist.



HEADQUARTERS

402 Kentucky Avenue
Indianapolis, IN 46225
Tel: 1-800-US-CHAIN
Fax: 1-317-613-2243

UNITED KINGDOM

Unit 7 – 9, Blaydon Industrial Park, Chainbridge Road
Blaydon on Tyne
NE21 5AB
PH: +44-191-414-8822

Please visit www.diamondchain.co.uk for more information.